

Linewidth Analyzer LWA-10k NIR




HighFinesse
The Standard of Accuracy

Analyzer Unit

Input	min.	max.	typ.
Wavelength range ¹⁾	1064 nm	1625 nm	1550 nm
Input power range	0.5 mW	8 mW	5 mW
Input power stability	± 5 %		
Laser type	CW, single-mode		
Input fiber type	SM or PM (recommended), FC/AP		
Scan stroke (@ fscan > 10 Hz)	—	40 MHz	

1) For customized wavelength ranges please contact: service@highfinesse.de



Linewidth Analyzer LWA-10k NIR



HighFinesse
The Standard of Accuracy

Analyzer Unit

Spectral and Frequency Noise Specifications²⁾

		10 Hz	100 Hz	1 kHz	10 kHz	100 kHz	> 1 Mhz
Noise floor $N_{\Delta\nu}$ @ typ. input power and wavelength ³⁾	Hz/ $\sqrt{\text{Hz}}$	200	100	30	20	15	10
Laser phase noise floor @typ. input power and wavelength ^{4) 5)}	rad/ $\sqrt{\text{Hz}}$	20	1	30 m	2 m	150 μ	10 μ
	dBrad/ $\sqrt{\text{Hz}}$	26	0	-30	-54	-76	-100
Equivalent interferometer signal noise @ typ. input power and wavelength ^{5) 6)}	rad/ $\sqrt{\text{Hz/m}}$	6.2 μ	3.1 μ	920 n	620 n	460 n	310 n
	dBrad/ $\sqrt{\text{Hz/m}}$	-104	-110	-120	-124	-126	-130
Frequency noise density range (Hz/ $\sqrt{\text{Hz}}$)		10 M					
Minimum intrinsic linewidth (Lorentzian linewidth)		< 2 kHz					
Effective linewidth range (β -separation)		< 1 kHz – 20 MHz					
Dynamic range		60 dB					


2) Specified for 5 mW input power at a wavelength of 1550 nm.

3) $N_{\Delta\nu}$ is the noise floor of the instrument in terms of the square root of the power spectral density of the frequency noise.

4) The phase noise floor corresponds to the noise floor of the square root of the power spectral density of the phase. It is calculated from $N_{\Delta\nu}$ by the formula $1/f \times N_{\Delta\nu}$. Additionally, phase noise is often specified in terms of $\mathcal{L}(f)$ which can be calculated with the formula $\mathcal{L}(f) = 1/f^2 \times N_{\Delta\nu}^2/2$.

5) Not included in the software, can be calculated by the user from exported data.

6) This is the calculated noise of the interferometer phase of a two path interferometer with length imbalance L (in meters). The calculation is performed for a given frequency noise density floor by $2\pi nL/c \times N_{\Delta\nu}$ with n being the refractive index of the reference fiber interferometer material and c being the speed of light in vacuum. Values in the table are given for an refractive index of $n=1.46$ and a reference length of 1 meter.



Linewidth Analyzer LWA-10k NIR



HighFinesse
The Standard of Accuracy

Analyzer Unit

Lineshape Specification

Effective linewidth range (optical linewidth) [curve fitting method]	< 5 kHz – 10 MHz
-------------------------------------------------------------------------	------------------

Dynamic range	60 dB
---------------	-------

Frequency noise bandwidth ⁷⁾	10 Hz – 10 MHz
-----------------------------------------	----------------

Miscellaneous

Interface	Ethernet and USB 3.0
-----------	----------------------

Analog output	$\pm 7.5\text{ V}$ (50 Ω)
---------------	-----------------------------------

Dimensions	440 × 340 × 155 mm
------------	--------------------

Weight	12.0 kg
--------	---------

Digitizer Module

Sample rate (Sa/s)	62.5 M
--------------------	--------

Resolution	16 bits
------------	---------

Acquisition time	1 ms – 100 ms
------------------	---------------


Evaluation time	10 ms – 1 s
-----------------	-------------

Interface	USB 3.0 type B
-----------	----------------

Dimensions	210 × 200 × 74 mm
------------	-------------------

Weight	2.0 kg
--------	--------

⁷⁾ According to a –3 dB criterion.



Linewidth Analyzer LWA-10k NIR



HighFinesse
The Standard of Accuracy

Software

Operating system	Microsoft® Windows® 10 or newer
CPU (recommended)	Intel® i5 8600 / AMD Ryzen™ 5 2600 or better
Memory (recommended)	16 GB RAM or more
Graphical evaluation options	Frequency noise density spectrum, lineshape spectrum, intrinsic (Lorentzian) linewidth, effective (optical) linewidth

Further Information

For further technical information, application examples, diagrams
and for customisation of linewidth analyzers please contact:

HighFinesse Service

service@highfinesse.de



HighFinesse GmbH
Wöhrdstraße 4
72072 Tübingen, Germany



T +49 (0) 7071 - 53 918 0
F +49 (0) 7071 - 53 918 99
M info@highfinesse.com



Additional information
and distributors:
www.highfinesse.com